





PR-01N-S

PR-01N-H


## **■ DESCRIPTION**


- It is a device to convert the axis of the shaft of the Encoder into an electrical pulse.
- divided by number of pulse
- Number of Pulse / Cycle can be selected from 25 2048 Pulse
- Push-Pull output can be used for both NPN, PNP Open Collector and Line Driver.
- Push-Pull output signal (A, B, Z) and Line-Driver (A, B, B, Z, Z)
- Power supply 8 30 VDC (Push-Pull) and 5 VDC (Line-Driver)

# **TECHNICAL SPECIFICATION**

Davies avents	Push-Pull	8-30 VDC		
Power supply	Line driver	5 VDC		
Power consumption		Max 42.5 mA		
Pulse/Round		25 - 2048 Pulse/Round		
		2- Phase+Index position		
Output wave from		A, B, Z and A, B, Z		
		Duty Ratio 50 %		
Rise/Fall time		100 ns.		
Max frequency response	oncse	200 kHz		
Max speed		20,000 RPM		
Ambient operation	Temperature	-10 °C to 60 °C		
Ambient operation	Humidity	80 % RH Non-Condensing		
Ambient storage	Temperature	-30 °C to 85 °C		
Ambient storage	Humidity	80 % RH Non-Condensing		
Protection degree		IP54		
Direction of rotation		Positive direction/Negative direction		
Housing diameter		50 mm.		
Shaft diameter		8 mm.		
Cable		50 cm. Shield cable		
	Cover	Steel		
Material	Encoder	Aluminium		
	Shaft	Stainless		
Weight		215 g.		

# DIMENSION






### OPERATION


Connect the shaft of the Encoder PR - 01N to the motor shaft or workpiece to measure. When the PR - 01N shaft rotates according to the motor, it sends a pulse signal according to the pulse per round of the model PR - 01N - S - 100 will be divided into 100 parts per 1 round. As the shaft moves, it sends the pulse out of the rotating parts. Signal A and Signal B Lead / Lag angle 90 degrees by the electric clockwise rotation A will lead B, but if turn counterclockwise B will be ahead of A, which will be useful to check the direction. The Signal Z will have 1 Pulse to inform you of the anniversary


If the line - driver output signal is 6 Signal is A, A, B, B, Z, Z by A will invert with A, B will invert with B and Z will invert with Z displayed by Signal Graph

#### **■ ORDERING CODE**





### **SIGNAL OPERATION GRAPH**





### **CIRCUIT OF OUTPUT SIGNAL**






### **WIRING DIAGRAM**


Push-Pull

The Shielded Wire is Connected to the main body.



## Line Driver

The Shielded Wire is Connected to the main body.




#### ACCESSORIES

PR-02N-08 COUPLING for PR-01N-S



- For PR 01N S
- It is a connector for welding the Encoder to Load or Motor.

### DIMENSION



Model	D1/D2	L	D	Torque	Angular	Material
PR-02N-08	8/8 mm.	25 mm.	22 mm.	2 N.m.	5 degree	Polyester Resin

🎥 บริษัท ไพรมัส จำกัด

119 ซ.สีมวงอนุสรณ์ ถ.สุทธิสารวินิจฉัย แขวงดินแดง เขตดินแดง กรุงเทพ 10400 โทร 0-2693-7005, 0-2277-8027 แฟ็กซ์ 0-2277-3565 E-mail : sales@primusthai.com